


Self Cleaning Trash Screens for Irrigation Water

USDA Agricultural Research Service, Northwest Irrigation and Soils Research Laboratory, Kimberly, Idaho



The Problem

Irrigation water from open ditches carries trash that blows in, grows in, washes in, and collects in the ditches. The trash plugs up siphon tubes, gated pipe gates, and sprinkler nozzles. Plugged tubes, gates, and nozzles cause skips and poor water distribution, and force irrigators to recheck their water sets often. Weed seeds from upstream fields and ditch banks also spread with the water across fields.

Screening out trash from irrigation water is easy. However, manually keeping trash screens clean requires constant attention. Water-driven mechanical trash screens have been used in open ditches for many years. However, mechanical devices in dirty irrigation water require regular maintenance and end up as part of the problem rather than the solution.

Turbulent Fountain "Bubbler" Screens for Piped Water




Pond weed accumulated on a bubbler screen. Pond weed is difficult to move off a screen. Perforated screen is smoother and works better with moss and pond weed.



Accumulated trash must be periodically cleared away from the edges of the screen.

Bubbler Screen Construction



Cross section of a bubbler screen built from a corrugated pipe with a poured concrete base.

- Use a sharp bend into the riser such as a welded 90 degree "miter" bend or a blocked-off tee, rather than a curved elbow fitting. Make the riser at least 2 feet long to evenly distribute the flow from the end.

Maintain at least $2\frac{1}{2}$ ft/sec water velocity in the riser. The table below shows required riser sizes. Constricting orifices inserted over the end of the riser can maintain the required velocity when flows decrease.

- Use about 20 mesh stainless steel screen. This screen will remove the larger weed seeds but still will pass the silt. Screens clogged with calcium deposits can be cleaned with a weak acid such as Muratic.
- Bubble Screens and Overfall Screens both require at least 8 inches of head loss or drop in the water surface to operate properly. Sometimes sufficient head can be gained by piping the water for a couple hundred feet.

If sufficient head cannot be generated, a mechanical screen must be used.

Flow Rate (cfs) (inches)	Riser Size (in)	Screen Diameter (ft)
1 50	8	4
2 100	10	5
3 150	12	5
4 200	15	6



Plugged gates cause uneven watering and skips.



Mechanical screens are often maintenance problems.




Typical irrigation water trash.



Horizontal Screens for Ditch Water

cleaning horizontal and turbulent fountain trash screens.

Turbulent self-cleaning screens were developed by the USDA - Agricultural Research Service in Kimberly, Idaho. Over 500 of these screens are being used by farmers in southern Idaho and eastern Oregon.



Cross section of an Overfall Screen below a check in a ditch showing an angle iron turbulence bar. Overall screens can also be placed below temporary checks in concrete ditches.



Large Overfall Screen at the sump inlet for several center pivot systems.



A rotating electric-powered bicycle wheel screen at a canal gate entrance.